



Overload Relay

Thermal Overload For Contactor MC 9~40A --- 3 elements			
Reference	Adjustment Range	Nominal Rating	Auxiliary Contact
DTH22b .52A	0.4~0.63 A	0.52A	1a1b
DTH22b .82A	0.63~1 A	0.82A	1a1b
DTH22b 1.3A	1~1.6 A	1.3A	1a1b
DTH22b 2.1A	1.6~2.5 A	2.1A	1a1b
DTH22b 3.3A	2.5~4 A	3.3A	1a1b
DTH22b 5A	4~6 A	5A	1a1b
DTH22b 6.5A	5~8 A	6.5A	1a1b
DTH22b 7.5A	6~9 A	7.5A	1a1b
DTH22b 8.5A	7~10 A	8.5A	1a1b
DTH22b 11A	9~13 A	11A	1a1b
DTH22b 15A	12~18 A	15A	1a1b
DTH22b 19A	16~22 A	19A	1a1b
Thermal Overload For Contactor 32~40A --- 3 elements			
DTH40b 15A	12~18 A	15A	1a1b
DTH40b 19A	16~22 A	19A	1a1b
DTH40b 22A	18~26 A	22A	1a1b
DTH40b 30A	24~36 A	30A	1a1b
DTH40b 34A	28~40 A	34A	1a1b
Thermal Overload For Contactor 50~85A --- 3 elements			
DTH85b 30A	24~36 A	30A	1a1b
DTH85b 34A	28~40 A	34A	1a1b
DTH85b 42A	34~50 A	42A	1a1b
DTH85b 55A	45~65 A	55A	1a1b
DTH85b 65A	54~75 A	65A	1a1b
DTH85b 74A	63~85 A	74A	1a1b
Thermal Overload For Contactor 100~125A --- 3 elements			
DTH100b 55A	45~65 A	55A	1a1b
DTH100b 67A	54~80 A	67A	1a1b
DTH100b 82.5A	65~100 A	82.5A	1a1b
DTH100b 105A	85~125 A	105A	1a1b
Thermal Overload For Contactor 150A --- 3 elements			
DTH150b 67A	54~80 A	67A	1a1b
DTH150b 82.5A	65~100 A	82.5A	1a1b
DTH150b 105A	85~125 A	105A	1a1b
DTH150b 125A	100~150 A	125A	1a1b
Separate Mounting unit for TH			
Reference	Overload Range		
SM-22	DTH22b		